



Figure 2

Assemblyng HAM SAS shipping crate:

1. With HAM SAS on trolley.

- 2. Wrap HAM SAS in UHV aluminium foil, then wrap in polyethylene foil. Mount the square tubes below the bare structure, figure 1. Then double wrap in polyethylene foil. Include silica gel bags in both wraps. Seal all around with heat welding, except for shaft region.
- 3. Bolt bottom crate below square tubes, figure 2.
- 4. Bolt front and back of crate to bottom, and shim sides with polyethylene foam
- or polyethylene wrapped shims (3 to 5 mm thick), figure 3. 5. Mount top on front and back, and on square tube shims, add polyethylene foam
- as needed, figure 4.
- 6. Lift crate on fork lift from the front or the back.
- 7. Remove shafts from HAM SAS side transport plates, figure 5.
- 8. Wrap in aluminium foil the free parts, then sequentially seal the opened parts of both polyethylene wrapping layer.
- 9. Mount sides on crate, with foam shim panels.
- 10. Lower crate on floor.

Unpacking, of course, will be the inverse process.

2

ref.		no	te		date	signature
			modification	IS		
					designed for R.De Salvo	
		LIGO PROJECT	Γ	draw. by G.Gennaro-PROMEC		
HAM-OPTICAL BENCH transport					date 24-11-06	
				+	LIGO-D051258-00-D	
					scale 1/6 A 1	
	9				1 ()	· · · · · · · · · · · · · · · · · · ·