



NOTES: LED1: TRANSMIT (BRIGHT) OR RECEIVE MODE
LED2: POWER
RTS SIGNAL SELECTS TX/RX MODE

AQUATICUS ROV

TITLE: RS485 to RS232 Converter

Document Number:
http://aquaticus.info/rs485_to_rs232

REV:
A

Date: 2006-12-06 21:59:02

Sheet: 1/1