


Panel D1400102-v2


System Status



High Voltage Output
To Fast Shutter




Fast Trigger
Input



Test Port



USB Programming
Interface



WARNING
HIGH VOLTAGES

Fast Shutter Driver
D1400078



Blanking
Output


Enable
HV Disable




HV Enabled
Fault



+15
-15



+5
+12



Fast Up
HV Ready



Slow Up
Slow Low

