



S2300057

LASER INTERFEROMETER GRAVITATIONAL WAVE OBSERVATORY

*LIGO Laboratory / LIGO Scientific Collaboration*

LIGO-E2300085-v1

*LIGO*

3/15/23

**Test Procedure for  
Drop in Replacement for Wenzel OCXO**

Daniel Sigg

Distribution of this document:  
LIGO Scientific Collaboration

This is an internal working note  
of the LIGO Laboratory.

**California Institute of Technology**  
LIGO Project – MS 18-34  
1200 E. California Blvd.  
Pasadena, CA 91125  
Phone (626) 395-2129  
Fax (626) 304-9834  
E-mail: [info@ligo.caltech.edu](mailto:info@ligo.caltech.edu)

**Massachusetts Institute of Technology**  
LIGO Project – NW22-295  
185 Albany St  
Cambridge, MA 02139  
Phone (617) 253-4824  
Fax (617) 253-7014  
E-mail: [info@ligo.mit.edu](mailto:info@ligo.mit.edu)

**LIGO Hanford Observatory**  
P.O. Box 159  
Richland WA 99352  
Phone 509-372-8106  
Fax 509-372-8137

**LIGO Livingston Observatory**  
P.O. Box 940  
Livingston, LA 70754  
Phone 225-686-3100  
Fax 225-686-7189

<http://www.ligo.caltech.edu/>

### 1 Introduction

The following Test Procedure describes the test of proper operation of the [Drop in Replacement for Wenzel OCXO](#).

S/N S2300057 Nominal Frequency: 203.125MHz / 200.105MHz / 203, 125

Tester J.S. Date 3/15/23

### 2 Test Equipment

- Voltmeter
- Oscilloscope
- RF Power Meter Agilent E4418A
- RF Frequency counter Agilent 53131A
- Board Schematics, LIGO D2200294.

### 3 Tests

Use clip doodles to apply +15V to the unit (J2/J3)

- 1) **Verify the proper current draw.** Using a bench DC supply apply +15Volts to J2/J3. Measure the current draw of the board.

+15 Volt current 160mA 0.03 A Nom. (30mA)

- 2) **On the board check.**

VCC (+3.3V) 3.31

S 2300057

- 3) Measure RF powers and RF frequencies as function of the tuning voltage. Use Frequency Counter to measure frequency, and power meter to measure power on J4 (SMA) while applying voltage to the TUNE input. Use voltage calibrator to apply voltage to the TUNE input J1.

| Port | Tune | Power dBm) | Freq. (MHz) | Nominal depending on OCXO |
|------|------|------------|-------------|---------------------------|
| J4   | 0V   | 17.2       | 203.079900  | >13 dBm                   |
| J4   | +5V  | 17.3       | 203.125060  | >13 dBm                   |
| J4   | +10V | 17.2       | 203.150010  | >13 dBm                   |

- 4) Measure the Phase noise of the Low Noise VCXO Output (Out) using the Wenzel single channel phase noise measurement technique (3.5.3), Figure 3.5.2-1, which can be found at [http://www.wenzel.com/wp-content/uploads/BP\\_1000\\_v1-05.pdf](http://www.wenzel.com/wp-content/uploads/BP_1000_v1-05.pdf).

A reasonable FFT analyzer is the SR785, which can be set to measure power units if you start in Display Setup. A Reference Source should be provided from the 203.125 MHz output of the D1100663 Multiple Frequency Oscillator (MFO), properly powered and connected to the Wenzel phase noise measurement system. The output of the Low Noise VCO will need to be attenuated by about 3 dB to provide the amplitude needed by the Wenzel phase noise measurement system (about 10 dBm).

For reference purposes, the oscillator being used inside is the Wenzel 500-30558, information for which can be found [here](#) and [here](#). For the purposes of this test, the REF oscillator phase noise ( $\mathcal{L}(f)^{REF}$ ) is considered unmeasured but calculated to be [ $\mathcal{L}(f)^{COMB} - 3 \text{ dB}$ ]; using these values,  $\mathcal{L}(f)^{DUT}$  can be calculated in section 3.5.3.4.

| Offset Frequency (Hz) | PSD Value (dBV <sub>rms</sub> /√Hz) | Mixer Slope (V/rad) | Amplifier Gain (dB) | VCXO noise ( $\mathcal{L}(f)^{DUT}$ ) |
|-----------------------|-------------------------------------|---------------------|---------------------|---------------------------------------|
| 10 Hz                 |                                     |                     |                     |                                       |
| 100 Hz                |                                     |                     |                     |                                       |
| 1 kHz                 |                                     |                     |                     |                                       |

Mixer Slope \_\_\_\_\_ mV / 0.02pi radians = \_\_\_\_\_