
To ISS Board
To Interface Board
To RM Chassis
From AI Chassis
aLIGO TCS Intensity Stabilization Servo
LIGO D1300015-v2 S/N
aLIGO TCS ISS Interface Board
D1300560-v1
S/N
TCS ISS Interface Board
D1800652-v1
From Power Board
High Voltage
Control
GND
-15V
+15V