Finesse Update

*

+ Noise Propagation-Simulation Tutorial



Andreas Freise
University of Birmingham

25.10.2007 AEI, Hannover



Finesse

- General purpose interferometer simulation for laser interferometers (C code, frequency domain)
- Finesse Home, Version: 0.99.5http://www.rzg.mpg.de/~adf/
 - Linux, Windows, OS X binaries
 - 140 pages manual
 - Simple example files
 - Java GUI Luxor (by Jan Harms)
- GEO Simulation Wiki http://www.sr.bham.ac.uk/dokuwiki/doku.php?id=geosim:finesse
 - GEO 600 input file with 18 pages manual
 - External tools (Matlab interface, Beowulf cluster scripts, ...)
 - Other GW detector input files (iLigo, eLigo, advLigo, Virgo, ...)
 - Talks and tutorials





Code Changes

- Mostly changing Finesse from being a 'personal' code project to an open and manageable structure:
 - Code has been cleaned and partly re-written
 - Documentation within the code has been improved a lot (using Doxygen)
 - Code has been moved to a subversion repository and is now regularly accessed by more than one developer (You can join in, if you would like to implement a new feature in Finesse)
 - Nightly builds and tests are performed (some unit tests, mostly consistency checks against reference input files)
- Most recent main feature: client server TCP/IP communication between Finesse and Matlab (see talk from last meeting)



25.10.2007 A. Freise



Matlab Interface

Finesse Matlab Establishes a TCP/IP Connection Finesse in server mode: katconnect(host, port) An input file has been loaded but the 'xaxis' command is ignored -Waiting for client connection Sends parameter name(s) 'm1 phi' m2kat(parameterlist) Receives number of outputs (pds) for i=0...100After receiving a input value, x=1*0.9Finesse sets the previously set Parameter(s) to that value ad Sends numeric value for 'm1 phi' out(i)=m2kat(x) computes ONE datapoint. end All outputs are computed and the Receives values for all outputs Values are send back to Matlab. ◆ The MathWorks (The parameter value remians At it's new value). katdisconnect Closing the connection





Quantum Noise, Radiation Pressure

Highest priority - but still work in progress Code h squeez 2.1e-10 The hal 2e-10 New Finesse command frequer 1.9e-10 'qshot' Genera 3 1.8e-10 (qshot 1.7e-10 shotnoi 1.6e-10 radiatid 1.5e-10 1.4e-10 1.3e-10 1.2e-10 100 20 40 60 80 120 140 160 180 dark fringe demodulation phase Schottky qshot





Status Summary

- Emphasis recently on using Finesse for GEO commissioning and providing more documentation, especially one more complex tasks
- Code changes focused on radiation pressure effects and on opening the project to new developers



25.10.2007 6 A. Freise



Tutorial: Transfer Functions and Noise Propagations with Finesse

- Basics about computing transfer functions
- The command fsig and how to use it
- Doing a noise propagation from transfer functions
- The GEO 600 case



25.10.2007 7 A. Freise



Transfer Functions

- In the frequency domain, transfer functions are computed by adding extra 'signal sidebands' to the system in the defined input and then computing their amplitudes in the desired output.
- The command

```
fsig name component [type] f, phi
```

is used to generate these sidebands

 A photodiode with demodulation (not the amplitude detector ad) is used to detect the signal amplitude


```
pd[n] name [f<sub>mod</sub> phi<sub>mod</sub> ...] f<sub>s</sub> phi<sub>s</sub>
```



25.10.2007 8 A. Freise



A Simple Example



Simple cavity: two mirrors + one space (4 nodes)


Light source (laser)

Output signal (detector)






Carrier light







Modulation sidebands




Demodulation process selects specific beat signals

pd1 pdh f_{mod} phi $_{mod}$ n1





Signal sidebands



One more demodulation gives the transfer function output:

pd2 pdh f_{mod} phi $_{mod}$ f_{s} phi $_{s}$ n1





Laser component:

Type of modulation	Unit	Syntax	comment
phase	rad	fsig sig1 phase laser f phi	
Amplitude		fsig sigl amp laser f phi	
frequency	Hz	fsig sigl freq laser f phi	

(The units of the transferfunction are W/[Signal Units])

Usage:

Note that signal sidebands added before a modulator are not being introduced to the modulation sidebands as well, which is not what happens in reality! Consequently the laser component should generally not be used with fsig when modulators are present (You can use a beam splitter instead, see following slides).





Modulator component:

Type of modulation	Unit	Syntax	comment
phase	rad	fsig sigl eom f phi	Oscillator phase noise
Amplitude		fsig sigl amp eom f phi	Oscillator amplitude noise (currently being implemented)



25.10.2007 14 A. Freise




Mirror or beam splitter component:

Type of modulation	Unit	Syntax	comment
phase of reflected light	rad	fsig sigl mirror f phi	Convert to [m] with the command scale meter
Amplitude of reflected light		fsig sigl amp mirror f phi	
Tilt of refl. light	rad	fsig sigl x/y mirror f phi	Works fine but tests are not yet completed

Usage:

 Use a dummy beam splitter component (in GEO use BDIPR) for computations relative power noise (RPN) or laser frequency noise



25.10.2007 15



Space component:

Type of modulation	Unit	Syntax	comment
phase of transmitted light	(strain)	fsig sigl space f phi	

Usage:

Correctly computes the signal beyond the long-wavelength approximation in simple configurations (i.e. orthogonal arms) .



25.10.2007 16 A. Freise




Example 1

- Detector commissioning, using the transfer function only:
 - Comparing a measured transfer function with a simulated transfer function
 - Using the GEO Finesse input file and only add:

```
pdl DPpow 1 nDPout
fsig sig1 BDIPR amp 1 0
xaxis sig1 f log 1 10000 1000
put DPpow f1 $x1
```

This gives the power noise transfer function into the dark port (here only with respect to the carrier light)

*





Example 2

- Projecting noise into the sensitivity plot:
 - Use a known or measured noise level (spectral density)
 - Compute the optical gain with Finesse (transfer function: differential end mirror motion into dark fringe)
 - Compute the apparent strain amplitude by dividing the noise spectrum by the optical gain



25.10.2007 19 A. Freise



GEO 600 Optical Gain

- The GW signal is detected in at least two electronic signals (inphase/quadrature, P/Q of the main photodiode)
- Reconstruction of GEO sensitivity uses a complex algorithm
- We need to compute the optical gain independently for P and Q:


```
fsig sig1 MCN 1 0 frequency 1 Hz, differential phase fsig sig2 MCE 1 180 pd2 pdMI1 $fMI 4 1 nMSR2 pd2 pdMI2 $fMI 101 1 nMSR2 xaxis sig1 f log 10 10k 300 put pdMI1 f2 $x1 put pdMI2 f2 $x1
```

There is always only one signal frequency!





GEO 600 Optical Gain







Optical Gain to Sensitivity

- Optical gain: TF in [W/m]
- Example shotnoise: We need to compute the shotnoise amplitude spectral density as S_{shot} in [W/sqrt(Hz)]
- Compute apparent displacement noise as:

$$S_{\Lambda L} = S_{shot} / TF \text{ in } [m/sqrt(Hz)]$$

 Or in the case of GEO: P and Q are computed separately and then merged with weighting functions:


$$S_{\Delta L} = sqrt(w_p^2 S_{\Delta Lp}^2 + w_q^2 S_{\Delta Lq}^2)$$

(These computations can be done within Finesse)





GEO 600 Sensitivity








... end.





Weights for P and Q Channel

Simple approximation of weighting functions:





25.10.2007 25 A. Freise