



LASER INTERFEROMETER GRAVITATIONAL WAVE OBSERVATORY

LIGO Laboratory / LIGO Scientific Collaboration

LIGO- E1100597-v1

Advanced LIGO

3 October 2011

Test Procedure for the N-N Balun Isolation Transformer

Daniel Sigg

Distribution of this document:
LIGO Scientific Collaboration

This is an internal working note
of the LIGO Laboratory.

California Institute of Technology
LIGO Project – MS 18-34
1200 E. California Blvd.
Pasadena, CA 91125
Phone (626) 395-2129
Fax (626) 304-9834
E-mail: info@ligo.caltech.edu

Massachusetts Institute of Technology
LIGO Project – NW22-295
185 Albany St
Cambridge, MA 02139
Phone (617) 253-4824
Fax (617) 253-7014
E-mail: info@ligo.mit.edu

LIGO Hanford Observatory
P.O. Box 1970
Richland WA 99352
Phone 509-372-8106
Fax 509-372-8137

LIGO Livingston Observatory
P.O. Box 940
Livingston, LA 70754
Phone 225-686-3100
Fax 225-686-7189

<http://www.ligo.caltech.edu/>

1 Overview

A balun isolation transformer blocks DC signals in an RF transmission line, [D1101077-v1](#). It is typically used to break ground loops between two remote rack locations. The test consists of measuring the transfer function of the DUT and verifying that the insertion loss is below a certain level.

2 Test Equipment

- Agilent network analyzer 4395A
- Power splitter, e.g., Mini-Circuits
- Coaxial cables

3 Testing

Measure a reference transfer function by using a barrel instead of the balun. Save both magnitude and phase.

Measure the transfer function of the balun and save both magnitude and phase.

Take the ratio between the two traces and determine the insertion loss and delay. Verify that

Test	Pass/Fail
Insertion loss between 200kHz and 100MHz is below 1.2dB	
Phase is $0^\circ \pm 5^\circ$ between 200kHz and 100MHz	