


# Transportation of Ultra-Stable Light via Optical Fiber





#### **Emily Conant**

Bard College, California Institute of Technology Mentors: Evan Hall, Rana Adhikari, Tara Chalermsongsak






### Outline

- Background/Motivation
- Thermal Noise
- Fluctuation Dissipation Theorem
- Pound-Drever-Hall Locking
- Coating Thermal Noise Experiment
- Work Completed
- Conclusions/Future Work



# Background/Motivation

- LIGO is a signal and power recycling Michelson interferometer with Fabry-Pérot arms
- Since the strain of a gravitational wave is weak, high precision is needed for detection
- Some limiting sources of noise are: Thermal noise, seismic noise and shot noise





### **Thermal Noise**

- Brownian Noise: Mechanical displacement from thermal fluctuations in dielectric coatings
- Thermo-optic Noise: Statistical fluctuations of the temperature of a system which are caused by random heat fluxes
- Thermo-elastic Noise: Changes in the linear expansion coefficient cause surface displacement
- Thermo-refractive Noise: Changes in refractive index from temperature fluctuations

# Fluctuation Dissipation Theorem

 Callen and Welton's FDT relies on the assumption that the response of a system in thermodynamic equilibrium to small forces being applied is analogous to the response of a system to random fluctuations

$$S_x(f) = \frac{k_B T}{\pi^2 f^2} [Re[Y(f)]]$$





### **Normal-Mode Decomposition**

Compute and sum up [Re[Y(f)]] for each normal-mode


#### **Direct Calculation**

$$S_x(f) = \frac{2k_B T}{\pi^2 f^2} \frac{W_{diss}}{F_0^2}$$




# Pound-Drever-Hall Locking

- Frequency locking a laser to a Fabry-Perot cavity that is known to be stable
- Adjust frequency of the laser to match the resonant mode of the cavity




# Coating Thermal Noise Experiment


- Two Fabry-Perot cavities with silica tantala mirror coatings are used
- Each cavity has its own stabilized laser, which is locked to the cavities with the PDH technique
- Cavities are kept in a temperature stabilized vacuum chamber
- Pick off light to use as frequency reference



## **Initial Setup**


- Mode-Matched into the fiber
- Double passed through AOM
- Look at beat frequency
- Measure PLL control signal








### **Noise Cancellation**



#### Scheme 1




- Uses 1 AOM
- Lock Optical Beat to Marconi to stabilize light





- Uses 2 AOMs
- Has been demonstrated before
- Inject negative first order beam into fiber input, second AOM is modulated such that the first order beam emerges and is double passed back through the fiber

Long-Sheng Ma, Peter Jungner, Jun Ye, and John L. Hall, "Delivering the Same Optical Frequency at Two Places: Accurate 10 Cancellation of Phase Noise Introduced by an Optical Fiber or Other Time-Varying Path," Optics Letters, Vol. 19, No. 21, 1994.




## Results








# Conclusions/Future Work



# LIGO Conclusions/Future Work





## Acknowledgments

- My mentors: Evan Hall, Rana Adhikari, Tara Chalermsongsak
- Alan Weinstein
- LIGO labs
- National Science Foundation (NSF)
- Fellow SURF students



Thank you!!

